








## CINO 1D/2D SCANNER SETUP SHEET RECKON CONFIGURATION

The following will add ~ at the start of the barcode keep the [CR] at the end of the barcode.

Scan each barcode from the top down.

 F_DEFAULT	Return scanner to factory default.
 PROGRAM	Enter programming mode
Preamble 	Record Preamble
 7	Set '~' Symbol 7E is the ASCII code for ~
 E	
 FIN (Finish)	Finish Preamble
 END (Exit)	Finish Programming